

ATLAS 600

600 LUMEN HYBRID SOLAR LANTERN & CHARGER


Read instructions prior to use. Refer to the instructions regarding any questions about the use of your ATLAS 600 Camping Lantern.


OPERATING YOUR HybridLight ATLAS 600



Rechargeable Cell Battery: 4000 mAh Lithium-Ion

Charge Output: 5V/IA





Read instructions prior to use. Refer to the instructions regarding any questions about the use of your ATLAS 600 Camping Lantern.

USING YOUR ATLAS 600 LANTERN

Operating Your Light

The On/Off button in the center of the lantern will operate between different lighting modes.

- · 1st click: Low LED light (25 lumens, 100 hours of light)
- · 2nd click: Medium LED light (120 lumens, 20 hours of light)
- · 3rd click: High LED light (600 lumens, 5 hours of light)
- · Press and hold the button to gradually increase the light intensity.

Charging Your Light

When the lantern is charging, by either solar or USB, the charging indicator will show a red light. The indicator will shine brighter with a stronger charge. After initially removing the product from its packaging, charge it fully with direct power before using the solar charger. Leaving your lantern charging for extended periods of time will not harm the rechargeable cell.

There are two ways to charge your light:

- 1. Micro USB port: Remove the plastic guard in front of your lantern and insert the micro USB cable into the smaller of the two ports, insert other end into any standard USB charger or suitable USB wall outlet. Typically 4 hours of charge time is needed to fully charge the lantern from a standard wall outlet if the lantern is completely drained.
- 2. Solar panel charge: Position solar panel into the brightest sunlight (or other lighting) possible, with direct light on as much of the panel as possible. Typically charges full in 19 hours of time depending upon brightness and intensity of light source, if the lantern is completely drained.

How to Charge Your Mobile Device or Tablet

Remove the plastic guard in front of the lantern and insert the larger end of the USB cable into the larger of the two ports. Insert the other end of the cable into compatible mobile device. This product will not charge a device when the flashlight battery is lower than 20%, in order to reserve power for the lantern.

PRODUCT WARNINGS

Do not use if broken, bent, cracked or damaged parts are present. Any light that appears damaged in any way or operates abnormally must be removed from service. Inspect before each use.

- · Do not disassemble the lantern. The LED's cannot be replaced.
- Do not operate lantern near fire, flammable liquids or in gaseous or explosive atmospheres.
- · Do not permit children to use lantern unsupervised.
- · Do not shine directly into eyes.
- Unplug unit before attempting any cleaning or maintenance.
- This device is water proof but is not intended for underwater use or submersion. Ensure the rubber guard is tightly in place
 prior to contact with water.

WARRANTY INFORMATION

Our products are warranted against all defects in material and workmanship, excludes abuse, misuse, modification or accidents. Before returning any product, a customer service representative must issue you a Return Merchandise Authorization number. Obtain a Return Merchandise Authorization number by calling customer support at 435-674-4700. Include the original receipt received with the merchandise and send the package to:

HybridLight LLC attn: Warranty Dept. 566 N. Dixie Dr. St. George, Utah 84770

visit us at www.HybridLight.com for more Amazing Products